

Standard Application Procedure

Process Description: Fire Retardant Parts
Applicable Technologies: SLS
Revision Level: A
Revision Date: May 2007

~~Fire Retardant Protoplass~~
~~Fire Retardant Protoplass~~
~~Fire Retardant Protoplass~~
~~Fire Retardant Protoplass~~
~~Fire Retardant Protoplass~~

Proto-Reinforcement Coating

Proto-Reinforcement Coating

Part

Supplies Needed:

- Proto-Reinforcement© Coating
- Fire Retardant Protoplass©
- Rags or Paper Towel

Step 1: Gather the above supplies.

Step 2: Following the Compound Application Procedure for Proto-Reinforcement© apply 2 layers of the Proto-Reinforcement©. SLS parts should be completely saturated by dipping or brushing.

Step 3: Following the Compound Application Procedure for Fire Retardant Protoplass© spray on 5 coats of Fire Retardant Protoplass©.